

Quick Start Guide | Symbian Series60 Smartphones

Before you start

This Driver operates with Symbian Series60 v2.0 and v2.1.

Check that the Fabric Keyboard has power. The Fabric Keyboard requires 2 x AAA batteries (supplied):

1. Remove the slide-on cover on the Fabric Keyboard
2. Insert 2 x AAA batteries in the correct orientation into the battery compartment
3. Replace the slide-on cover

Installing the Driver

Your Smartphone requires a Driver in order to connect to and operate with the Fabric Keyboard. To install the Driver:

1. Insert the supplied Fabric Keyboard CD into your PC
2. Connect your Smartphone to the PC using a Bluetooth or InfraRed connection
3. Transfer the files '**FabricKeyboard.sis**' and '**FabricKeyboardBranding.sis**' from the CD to your Smartphone

Note: the files on the CD may be supplied 'zipped' if this is the case they must be 'unzipped' before being transferred.

Note: the '**.sis**' files must be installed in the correct order, they will appear in the Smartphone's inbox from where they can be installed automatically.

Troubleshooting: if the following message appears "**Application is untrusted and may have problems. Install only if you trust provider.**" select '**Yes**' and continue.

4. Install the first file '**FabricKeyboard.sis**' by opening it from the Smartphone's inbox
5. Install the second file '**FabricKeyboardBranding.sis**' in the same way

Installation is now complete. The '**Fabric Keyboard**' application will appear in the Smartphone's '**Menu**'.

Connecting to the Fabric Keyboard

To connect the Fabric Keyboard to your Smartphone:

1. Turn the Fabric Keyboard ON by pressing the ON/OFF button for at least 2 seconds until the green light is ON constantly
2. Launch the '**FabricKeyboard**' application (from '**Menu**')
3. On the opening screen, select '**Options**'
4. If connecting the Fabric Keyboard for the first time, select '**Find New Keyboard**'

Note: if a connection has previously been made select '**Disconnect**' and then select '**Find New Keyboard**'(if message '**Max no of Bluetooth connections**' appears select '**Find New Keyboard**' again as there is often a delay in disconnection.

Quick Start Guide | Symbian Series60 Smartphones

Troubleshooting: if message *'Max no of Bluetooth connections'* appears, open the *'Bluetooth Manager'* (*'Menu'* > *'Connect'*) and remove other active Bluetooth pairings - repeat the *'Find New Keyboard'* process.

5. After a period of searching the *'Elekсен'/ 'ElekTex Keyboard'/ 'ElekTex'/ 'keyboard'* device will be displayed, select it and wait for the *'Keyboard Found'* confirmation window

Connection is now complete. Follow the on-screen prompts to perform a calibration (this is recommended, see User Guide for details)

Note: the *'Fabric Keyboard'* application must remain open when using the Fabric Keyboard. Selecting *'Options'* and then *'Exit'* will close the application and disconnect the Fabric Keyboard. To leave the application running, select *'Back'* from the opening screen.

Troubleshooting

Phone will not pair with the Fabric Keyboard?

- Check that the phone's Bluetooth is ON from the *'Bluetooth Manager'* (*'Menu'* > *'Connect'*)
- Check that there are not too many active Bluetooth connections running (you may need to delete some if necessary)
- Check that the Fabric Keyboard is ON and in pairing mode (the green light should be on constantly)

The characters appearing on screen are not as typed?

- Perform a calibration. From the *'Fabric Keyboard'* application select *'Options'* > *'Calibration'* > *'Start Calibration'* and follow the on-screen instructions

Bluetooth will not turn ON within the Smartphone menu?

- Power cycle the Smartphone (turn the phone OFF and then back ON again)

Disclaimer: G-Tech warrants its product to be free from defects in material and workmanship for a period of six months from the date of purchase. For warranty service, buyer must provide a copy of the original receipt showing the date of purchase. Warranty applies to original purchaser only and is non-transferable.

If a defect occurs, G-Tech will, at its sole discretion, repair or replace the defective unit. If warranty service involves the exchange of a product, or a part of that product, the item replaced becomes the property of G-Tech. G-Tech reserves the right to use reconditioned parts that are equivalent or superior to original factory specifications. Replacement parts are warranted to be free from defects in material or workmanship for a period of thirty days from the date of repair, or for the remainder of the original period of limited warranty for the product, whichever is longer.

If the customer authorizes G-Tech to perform any services excluded under this limited warranty, the customer is responsible for standard repair fees for such work.

This warranty covers only the normal use for which the product is designed. This warranty does not cover any third party parts, components, or peripheral devices added to G-Tech product, or damage related to accidents, misuse, improper installation, negligence or shipping.

For warranty service, please contact G-Tech for a Return Authorization Number (RAN) and return the product, along with dated proof of purchase and RAN to G-Tech at the following address: 5911 Schaefer Ave., Chino, CA 91710. Please allow approximately 30 days from the date G-Tech receives the product for warranty service repairs.

ETP-1835